

智能指纹门禁机

使用手册

安装前请仔细阅读，并妥善保管好此手册以备随时查阅

一、设备参数:

产品名称	智能指纹门禁机
操作系统	实时操作系统
屏幕尺寸	1.77英寸显示屏
面板材质	亚克力加强面板
用户容量	指纹: 300枚 IC卡: 1000 密码: 1000
供电要求	DC12V 1.2A
电流	静态工作电流80mA / 工作电流500mA
通讯方式	涂鸦蓝牙和配
语音显示	简体中文/繁体中文/日本語/English/Francaise/Deutsch/Italiano/Portuguese/Arabic/Hebrew/Thai/Indonesian/Tagalog
门禁功能	门开/手动开门
识别方式	密码/IC卡/活体指纹
工作温度	20摄氏度至50摄氏度
语音提示	高清晰度人性化语音

二、产品结构功能示意图

三、产品接线示意图

四、线序说明

序号	引脚	颜色	说明
1	VCC	红	电源正极
2	GND	黑	电源负极
3	DO	黄	门磁信号线 (NO/NC)
4	COM	蓝	门磁信号线 (COM)
5	NO	绿	门磁信号线 (NO)
6	DO	黄	门磁信号线 (DO)
7	NC	紫	门磁信号线 (NC)
8	ALARM	棕	报警信号线
9	ALARM	棕	报警信号线

五、灯光指示及按键操作方式

1、灯光指示

- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮

2、按键操作

*键返回，#键确认，2键上翻，0键下翻，长按2键快速上翻，长按0键快速下翻。

六、菜单操作

1、操作说明

- 待机输入“*”，#进入系统菜单，*为待机状态和门磁状态指示，“#”为门磁输入系统菜单。
- 系统注册第一个默认认为管理员，可登记为指纹、密码或卡，第二个以后默认为普通用户，可修改为普通用户。
- 普通用户指纹或密码或卡输入3次错误，系统提示该用户状态。
- 普通用户输入密码或卡输入3次错误，系统提示该用户状态。
- 普通用户输入密码或卡输入3次错误，系统提示该用户状态。

2. 系统菜单显示

系统菜单显示+语音提示，用户可根据提示进行相应操作。

3. 常开模式

- 在待机状态下，长按“*”键，进入待机状态，显示待机状态指示。
- 在待机状态下，长按“*”键，进入待机状态，显示待机状态指示。

七、涂鸦蓝牙设置

1. 下载涂鸦APP

- 使用你的手机扫描以下二维码下载APP，或直接在应用商店搜索涂鸦APP。

2. 注册与登录

- 进入涂鸦APP，点击“注册”，输入手机号和密码，设置密码。
- 用户也可通过QQ或微信登录，经过授权后，即可登录系统。

3. 添加设备

- 进入涂鸦APP，在首页点击右上角“+”添加设备，进入“添加设备”页面，点击右上角“+”添加设备。

4. 临时开锁设置

- 进入涂鸦APP，在首页下方点击“家人”，进入“家人管理”页面，点击右上角“+”添加临时开锁。

5. 用户管理

- 进入涂鸦APP，在首页下方点击“家人”，进入“家人管理”页面，点击右上角“+”添加临时开锁。

5. 涂鸦蓝牙设置

1. 下载涂鸦APP

- 使用你的手机扫描以下二维码下载APP，或直接在应用商店搜索涂鸦APP。

2. 注册与登录

- 进入涂鸦APP，点击“注册”，输入手机号和密码，设置密码。
- 用户也可通过QQ或微信登录，经过授权后，即可登录系统。

3. 添加设备

- 进入涂鸦APP，在首页点击右上角“+”添加设备，进入“添加设备”页面，点击右上角“+”添加设备。

Intelligent fingerprint access control machine

user's guide

Please read carefully before installation and use this manual properly to avoid damage

I. Equipment parameters:

product name	Intelligent fingerprint access control machine
operating system	Real-time control of the operating system
screen size	A 1.77-inch TFT display screen
user capacity	Fingerprint: 300 pieces IC card: 1000 Password: 1,000
Power supply requirements	DC 12V 1.2A
current	Static working current is 80mA / working current is 500mA
communication mode	Bluetooth, standard for teeth
language display	Simplified Chinese / Traditional Chinese / Japanese / English / French / German / Italian / Portuguese / Arabic / Hebrew / Thai / Indonesian / Tagalog
Access control function	Doorbell / manual door opening
BM	Password / IC card / live fingerprint
working temperature	20 °C to 50 °C
Voice Prompt	High definition and humanized voice

2. Product structure and function diagram

three. Product wiring schematic diagram

Four, the line order description

Line	Color	Signal	Description
1	VCC	Red	Power supply positive
2	GND	Black	Power supply negative
3	DO	Yellow	Door lock signal (NO/NC)
4	COM	Blue	Door lock signal (COM)
5	NO	Green	Door lock signal (NO)
6	DO	Yellow	Door lock signal (DO)
7	NC	Purple	Door lock signal (NC)
8	ALARM	Brown	Alarm signal
9	ALARM	Brown	Alarm signal

五、灯光指示及按键操作模式

1. 灯光指示

- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮
- 待机: 常亮

2. 按键操作

*键返回，#键确认，2键上翻，0键下翻，长按2键快速上翻，长按0键快速下翻。

六、菜单操作

1. 操作说明

- 待机输入“*”，#进入系统菜单，*为待机状态和门磁状态指示，“#”为门磁输入系统菜单。
- 系统注册第一个默认认为管理员，可登记为指纹、密码或卡，第二个以后默认为普通用户，可修改为普通用户。
- 普通用户指纹或密码或卡输入3次错误，系统提示该用户状态。
- 普通用户输入密码或卡输入3次错误，系统提示该用户状态。
- 普通用户输入密码或卡输入3次错误，系统提示该用户状态。

2. System menu signal

系统菜单显示+语音提示，用户可根据提示进行相应操作。

3. Regular open mode

- 在待机状态下，长按“*”键，进入待机状态，显示待机状态指示。
- 在待机状态下，长按“*”键，进入待机状态，显示待机状态指示。

Seven, Doodle Bluetooth Settings

1. Download the Doodle APP

- Use your phone to scan the QR code below to download the APP, or search and download the APP in the app market.

2. Register and log in

- To use the Doodle APP, click the login button, enter the account and log in. Those who have no account need to register an account first. So users can also use QQ or Wechat to log in, after the authorization page, you can log in the system.

3. Add equipment

- After opening the APP, click the add device "+" on the top right of the home page and enter the "Add Device" page. Open the Bluetooth function. The Android phone will set the top of the home page, and the automatic search device will be displayed for matching.

4. Temporary unlocking setting

- Enter the Doodle APP, click the "Family" button at the bottom left of the home page to enter the "Family member" page. Click "+" on the top right to go to the machine password data and other settings.

5. User management

- Enter the Doodle APP, click the "Family" button at the bottom left of the home page to enter the "Family member" page. Click "+" on the top right to go to the machine password data and other settings.

Warranty needs to be known

In order to safeguard your interests, we have set up a warranty system in accordance with the national three-year warranty to provide you with a year of quality warranty service.

Product failure or damage in the following conditions are not included in the warranty:

- Product failure or damage caused by assembly, repair, change or disassembly of the product parameter not according to the machine anti-disassembly label has been marked, changed or lost;
- Product failure or damage caused by the use of parts not licensed by the manufacturer;
- Product failure or damage caused by the use of non-company special products (such as counterfeit, fake, etc.);
- Product failure or damage caused by force majeure such as natural disasters (such as earthquake, fire, etc.);
- No warranty card, valid invoice or purchase certificate;
- Product failure or damage caused by force majeure such as natural disasters (such as earthquake, fire, etc.);

Service records:

After opening the APP, click the add device "+" on the top right of the home page and enter the "Add Device" page. Open the Bluetooth function. The Android phone will set the top of the home page, and the automatic search device will be displayed for matching.